



Smart Metered Tannin + Water Softener

Installation / Operation Manual

Model #: KINDTS-1044

kindwater.com


Have questions? Call us: 888-614-5559

KIND WATER



EDUCATION

KINDTS-1044-REV-A-JU24



Softener Specifications.....	Page 3
Softener Installation.....	Page 5
Utilizing Bluetooth.....	Page 10
Programming the Control Valve.....	Page 12
Control Valve Powerhead Assembly.....	Page 18
Master Programming.....	Page 20
Valve Body Assembly.....	Page 23
Bypass Assembly.....	Page 25
Service Instructions.....	Page 26
Troubleshooting.....	Page 29
Error Codes.....	Page 31
Warranty Information.....	Page 32

General Specifications	KINDTS-1044
Grains capacity – Regeneration/lbs. of Salt Used	24,000/12
Salt Used / Regeneration (lbs)**	12
Maximum Raw Water Hardness (grains)	50
Maximum Clear Iron / Manganese (ppm)	.50
Exchange Resin (cu ft)	.50
Tannin Resin (cu ft)	.50
Mineral Tank Size	10 x 44
Brine Tank (polyethylene with grid & safety)	16 x 33
Service Flow Rate (gpm)*	11.0
Backwash Flow Rate (gpm)	1.5
Gallons Used / Regeneration	80
Space Required (D x W x H)	16 x 26 x 53
Approximate Shipping Weight (lbs)	75

WARNING

Lubricants

Do NOT use Vaseline, oils, hydrocarbon lubricants or spray silicone anywhere! Petroleum base lubricants will cause swelling of o-rings and seals. The use of other lubricants may attack plastic Noryl®.

Sealants

Pipe dope and liquid thread sealers may contain a carrier that attacks some plastic materials. It is recommended that Teflon® tape be used to seal plastic Noryl® threaded fittings.

PLEASE NOTE THESE SPECIFICATIONS BEFORE PROCEEDING

- ▲ **Operating Pressure Range:** 20 - 125 PSI
Operating Temperature Range: 33° F - 120° F
Inlet / Outlet Pipe Size: 1": FNPT
- ▲ Please comply with all applicable plumbing codes
- ▲ Protect the softener and piping from **FREEZING TEMPERATURES**

Please read the entire Installation/Operations before installation.
This Installation/Operations Manual must stay with the unit.

How A Water Softener Works

Water hardness is derived from Calcium and Magnesium minerals that have been dissolved into the water under the earth's surface. These minerals are found in limestone deposits and are the source of hard water. The amount of hardness in a given water supply is dependent upon the quantity of Calcium and Magnesium present and the length of time water has been in contact with them. This can vary dramatically from well-to-well and, for this reason, a water analysis is imperative in order to determine the proper treatment method. The degree of hardness increases as the concentration of Calcium and Magnesium "ions" increase and is measured in **Grains Per Gallon (gpg)**.

The problem of hard water in the home comes to light in many facets of daily use. Water spots and scum left behind on bathtubs, fixtures and showers; wear and tear on appliances; calcium build-up in hot water heaters and piping; and, greater amounts of soap and detergents being used are just a few examples.

The modern water softener is designed to reduce hardness ions and their unpleasant side effects. Special resin beads in the softener mineral tank are used to change hard water into soft water. The surfaces of these beads are covered with sodium ions. As hard water enters the mineral tank and comes into contact with the resin, an exchange of ions takes place as dissolved Calcium and Magnesium ions cling to the resin surface and sodium ions take their place, thus softening the water. This process is called **Ion Exchange**. Over time, the sodium ions used for the exchange process become depleted and must be replenished.

The water softener provides a **Regeneration** process whereby brine solution enters the mineral tank, driving-off the collected hardness ions and replenishing the surface of the resin beads with more sodium ions. This process is automatically initiated by the control valve on the mineral tank. The regeneration process has five basic cycles as follows:

1. **Backwash** - The control valve directs the water flow in a reverse direction through the mineral tank, separating the resin beads and flushing any accumulated particles to a waste drain.
2. **Brine & Rinse** - In the first part of this cycle, the control valve directs brine solution downward through the mineral tank, driving-off collected hardness ions and replenishing the resin beads with sodium ions. The second part of the cycle rinses hardness ions and excess brine from the mineral tank to the waste drain.
3. **Rapid Rinse** - The control valve directs the water flow downward, settling and recompacting the resin bed.

1. **Brine Refill** - The control valve directs fresh water into the salt compartment to create new brine solution for the next scheduled regeneration.
2. **Service** - This is the normal "operating" cycle where hard water enters the mineral tank, comes into contact with the resin beads and exchanges hardness ions for sodium ions - the water then becomes "soft" and ready for use.

Installation

Pre-Installation Check List

A Kind Water Test & Survey should always be performed in order to determine total water hardness (in gpg) and total dissolved iron (in parts per million - ppm). This is critical for proper equipment selection, sizing and for determining the program for regeneration frequency. If heavy concentrations of iron (above 5 ppm), iron coloration, iron bacteria or sediment are present, filtration prior to the softener will be required. Certain states may require a licensed plumber for installation.

NOTE

Flexible water supply connectors and flexible drain line tubing may not be allowed in you locale. Please check with local plumbing code officials prior to installation.

Installation Requirements

- A level floor position ahead of piping into water heater.
- Unit must be installed at least 10' ahead of the inlet to a water heater to prevent damage due to back-up of hot water.
- **DO NOT** install the unit in an area of direct sunlight or where freezing temperatures may occur! (See Installation Diagrams for proper placement and plumbing connections.)

Major System Components


Brine Tank - This tank holds the salt that is added to the softener. This salt is dissolved with water to form a brine solution used in the softener regeneration process.

Resin Tank - This tank contains tannin removal resin and ion exchange resin media. Water flows through the resin tank under pressure to come into contact with the resin for water softening and tannin removal.

Control Valve - The valve directs water through the resin tank for water softening and controls the flow of water / brine for the regeneration process.


TWO TANK SETUP

(Incoming Water from Left-Side)



TWO TANK SETUP

(Incoming Water from Right-Side)



Softener Location / Other Requirements

1. Locate the unit near an unswitched, 120 volt / 60 Hz grounded electrical outlet.
2. Check for distance and proper drain installation (e.g. floor drain, washing machine standpipe).
3. Determine type and size of piping required for softener connection (e.g. copper, galvanized, PVC plastic).

NOTE

- If household plumbing is galvanized and you intend to make the installation with copper (or vice versa), obtain di-electric unions to prevent dissimilar metal corrosion.
- Where the drain line is elevated above the control valve or exceeds 20 feet in length to reach the drain, use 3/4" I.D. drain line tubing instead of 1/2" I.D.
- All plumbing lines not requiring "soft" water should be connected "upstream" of the softener.
- The brine tank drain line is gravity flow and must discharge below the overflow fitting.
- The brine overflow is provided as a back-up in the event the safety float shut-off should fail, allowing the brine tank to overflow. This drain connection would then carry the excess water to the drain and prevent flooding of the floor. Therefore, no liability will or can be assumed by the manufacturer of the softener should this occur.

CAUTION

- If sweat soldering copper pipe (remember to always use lead free solder and flux), cover bypass valve with wet rags to prevent heat damage to connections and control valve! If using PVC or plastic pipe primers and solvent cements specifically recommended for use with potable water are required.
- Do not "TEE" to the main drain line from control valve.

Installation Procedure


See the well water systems installation video: <https://kindwater.com/educationcenter/>

Water Supply Connections and Bypass Valve

To allow for softener servicing, swimming pool filling or lawn sprinkling, a manual bypass valve has been installed at the factory. The bypass allows hard water to be manually routed around the softener.

- 1 Position softener at desired location for installation.
(See Installation Diagrams.)
- 2 Turn OFF main water supply and OPEN nearest faucet to relieve pressure.
- 3 Cut main line and install appropriate elbows and extensions.
Inlet and outlet connections on the control valve are 1"

Bypass - Shown



CAUTION

Raised arrows located on the sides of control valve body and bypass valve indicate proper direction of water flow. Install inlet and outlet piping in direction of arrows. It is recommended that a vacuum breaker be installed on the inlet plumbing.

- 4 Rotate bypass valve to the bypass position (position of lever is at right angle to inlet / outlet piping).
- 5 Turn the main supply line on to restore water service to the home.
- 6 OPEN nearest faucet to evacuate air and repressurize plumbing lines.
- 7 Check for leaks!

Drain Line Connection

- 1 The drain line flow control assembly is pre-assembled for your convenience. Should you choose to hard plumb the drain line, please remove the barb fitting. The flow control housing can be removed by removing the clip and pulling straight out on housing.

NOTE

When re-installing the drain line flow control housing, be sure you hear and feel the O-Ring pop into place before inserting the clip.

- 2 Install 1/2" I.D. drain line tubing from hose barb to an open drain. A 4" gap between end of the drain line and the open drain is required to prevent waste water backflow. Keep the drain line as short as possible. An overhead drain line can be used if necessary, but should discharge below the control valve. A siphon trap (taped loop) at the outlet of the drain line is advisable to keep the drain line full and assure correct flow during backwash. Elbows or other fittings must be kept at a bare minimum.

NOTE

Where the drain line is elevated above the control valve or exceeds 20 feet in length, 3/4" I.D. drain line tubing should be used.

KIND WATER




EDUCATION

Brine Line and Overflow Connection


Note: Your brine tank comes with two brine lines. Black is for outdoor installation. Opaque is for indoor installation.

Feed one end of brine line to brine line connection on control valve. Firmly insert it all the way into the push lock fitting. When the tubing is fully inserted, the fitting will grab the tubing and hold it in place. A compression insert is NOT needed.



BRINE LINE CONNECTION TO CONTROL VALVE

Inside the brine tank, remove the cap from the top of the brine well. Feed the other end of the brine tubing through the hole in the side of the brine tank, and firmly insert it all the way into the push-lock elbow fitting inside the brine well. When this tubing is fully inserted, the fitting will grab the tubing and hold it in place.



BRINE LINE CONNECTION TO BRINE TANK

Electrical Connection

Connect the power cord and plug power supply into a 115 volt / 60 Hz receptacle.

NOTE

Do not plug into an outlet controlled by a wall switch or pull chain that could inadvertently be turned off

Electronic Connections

P = Power Supply

B = Powered in Backwash Step Only
(Cycle #1)

S = Powered for Entire Regen. Cycle



Pressurizing The System

- 1 Make certain Control Valve is in **SERVICE** position.
- 2 Slowly rotate bypass valve to the **SERVICE** position. (Position of bypass lever is parallel to inlet / outlet piping.)
- 3 Open the nearest faucet to evacuate air from plumbing lines.
- 4 Check for leaks! If water is observed leaking from bottom of bypass, close and open bypass lever several times to seat o-rings. Exercise bypass valve.
- 5 After air is evacuated from plumbing lines, close bypass (position of bypass lever is perpendicular to the direction of inlet pipe) on bypass valve.



Utilizing Bluetooth Control

For simplified set up and control, please install the Kind Water app on a compatible Bluetooth 4.0+ enabled smart phone or tablet.

- 1 Download and install the Kind Water app from the Google Play Store, Apple App Store





- 2 Open the Kind Water app
 - Choose a valve device at any time from the list of available devices to connect to by clicking on it.
 - If the valve you want to connect to doesn't show up, or there is a problem connecting to a device you can press the "Scan for Devices" button or the Kind Water logo at any time to refresh the list and start the process over.
- 3 BTLE Valve devices can be updated by the App. When the app is updated from the Google Play Store or the Apple App Store, it may contain an updated firmware program for the valve devices. These updates could contain new features or operational improvements. It is up to the user to allow these updates to be sent to the valve device. Uploading a new program takes approximately 1 minute.

Dashboard


NOTE Consult your dealer before making any changes

From the **Dashboard**, all items in **GREEN** can be changed, while blue fields are informational only.




If you are unsure about the function of the field click the  for more information.

Set Up Utilizing Bluetooth App



Change Time of Day


(Press "SET" to set time automatically based on device).



For Filters:

Set Backwash Frequency

This sets the amount of day between backwash cycles



Set Regeneration Time

EXAMPLE For 2 a.m., just type 2, choose a.m., and press 'OK'

NOTE If you have a filter and a softener the valves should be set to regenerate at different times. Factory default times are 12a.m. for filters, and 2 a.m. for softeners.


Advanced Settings

NOTE Consult Kind Water’s Technical Support Team at 888-614-5559 before making any changes. We do not recommend changing Advanced Settings unless you have a good understanding of the system operation.

From the **Advanced Settings**, all items in **GREEN** with a “set” button can be changed.


Status and History

From the **Status and History**, all items in **GREEN** can be reset.



Touch any table to explode
a detailed list of the last 60 days.


1 Start a regeneration or backwash cycle




Option 1

Click the "Regenerate Unit Now."

Once a regeneration has been started, if you would like to force the unit into the next cycle step click "Go to Next Regeneration Step".



Option 2



"Regenerate Unit at Next Regen Time" button.

This will take the system into a backwash cycle at the next regeneration time.

Programming The Control Valve

1 Set time of day.

2 Set a.m. or p.m.

3 Set water hardness in grains per gallon (gpg).

NOTE

If the water contains iron and / or manganese, multiply the total parts per million (ppm) by "four" (4) and then add to the grains per gallon (gpg) of hardness. Use this COMPENSATED HARDNESS level when programming the regeneration frequency.

4 Set regeneration day override if other than (7) days is desired. (This is particularly useful when iron is being treated to prevent fouling of the resin.)

5 Set regeneration time, if other than 2:00 a.m. is desired.

NOTE

Salt settings are pre-set at the factory for the maximum shown on the capacity charts.

CAUTION

Do not reduce salt settings below 9 lbs. as the water level in the brine tank will not reach the grid plate.

Control Valve Operation

- 1 Advance control valve to BACKWASH (cycle 1) position and allow water to run to drain for 3 to 4 minutes.

CAUTION

Close valve on bypass prior to selecting the backwash position. After backwash position has been established, slightly open bypass to evacuate air from the media tank. Fully open valve when all air is depleted. This procedure will prevent media from being uplifted into control valve.

- 2 Advance control valve to BRINE REFILL (cycle 4) position and allow the brine tank to fill just over the salt grid
- 3 Advance control valve to BRINE & RINSE (cycle 2) and allow the control valve to draw water from the brine tank until it stops. If no draw is observed, check tightness of brine line compression fittings.
- 4 Advance control valve to RAPID RINSE (cycle 3) position and let run to drain for 3 - 4 minutes.
- 5 Advance control valve to BRINE TANK REFILL (cycle 4) position and allow the control valve to automatically fill the brine tank.

NOTE

Control valve will advance to service position automatically.

Start Up Procedure

- 1 Put unit in bypass using the handles behind the control valve.
- 2 Start a regeneration by pressing and holding the set change button for 3 seconds.
 - The display may show zeros or a 1, repeat holding the set change button.
- 3 Display on unit should read 1-10 (Step 1-10 min). Very slowly open the inlet bypass to remove any remaining air.
- 4 After the inlet bypass has been fully opened slowly, open the outlet bypass and let unit backwash for 2 minutes or until water is clear. Verify water is going to drain.
- 5 Fill the brine tank with a 5-gallon bucket of water and add the provided Sani pack.
 - If you have already added salt, then pour the water and Sani pack down the white 4in brine well cylinder.
- 6 Advance unit to next regeneration cycle (Step 2-Brine draw) by holding the set change button for 3 seconds.
- 7 Stay in (step 2- Brine draw) for an additional 10 minutes and verify all water has been drawn out of the brine tank.

Installation

- 8 Advance unit to next regeneration cycle (Step 3-Rapid Rinse) by holding the set change button for 3 seconds. Stay in this step for 2 minutes. Verify water is going to drain.
- 9 Advance unit to next regeneration cycle (Step 4- Brine fill) by holding the set change button for 3 seconds. Let this step continue until minutes remaining are zero and the time of day appears on display.
 - When finished the brine tank should have water above the salt grid.
- 10 Lastly add salt to the brine tank. Do not fill salt higher than the brine well.

Final Check

- Be certain the bypass valve is in the SERVICE position.
- Make sure the power supply is connected to an uninterrupted 115-volt outlet.
- Check that the time of day is set
- Double check regeneration schedule.
- Make final check for leaks!

Operation, Care and Cleaning

When the bypass valve is in the SERVICE position (position of bypass lever is parallel to the inlet / outlet piping), water is directed through the water softener. Water may be bypassed by turning the lever to the bypass position (position of bypass lever is at right angles to inlet / outlet piping). Water to the home will bypass the softener and be untreated.

You should manually bypass the softener if:

- The outside lines do not bypass the water softener and water is to be used for lawn sprinkling or other similar uses.
- Servicing the water softener.
- A water leak from the water softener is evident.
- Shock treating water well and piping with chlorine or other disinfectant.

Extra Regeneration

- If soft water demands are unusually heavy, an extra regeneration can be initiated manually :

To Skip A Regeneration


- For vacations or extended periods of absence, the power supply can be disconnected from the control valve. It is recommended that the 9-volt battery be removed.
- Upon return, plug in cord and reset the time of day. Replace 9-volt battery.

General Care and Cleaning

- Do not place heavy or sharp objects on water softener.
- Use only mild soap and warm water to clean exterior of the unit. Never use harsh, abrasive cleaners.
- Protect the water softener and drain line from freezing.
- Reset time for daylight saving time periods.
- Replace 9-volt battery once a year.
- Inspect and clean the brine tank when sediment appears in the bottom of the salt compartment.
- Always keep the brine tank supplied with good quality salt, a type designed for use in water softeners.

Programming The Control Valve

Main Menu



MENU / ENTER BUTTON

SET / CHANGE BUTTON

- 1** To enter Main Menu, press the **Menu/Enter** button.
(Time of Day will flash)
- 2** To set the Time of Day, press the **Set/Change** button.
(First digit will flash)
 - To change digit value, press the **Set/Change** button.
 - To accept the digit value, press the **Menu/Enter** button.
 - Next digit will flash to begin setting.
 - Once the last digit display is accepted, all digits will flash.

EXAMPLE [12-00]

- 3** To set **A.M.** or **P.M.**, press the **Menu/Enter** button.
 - To change digit value, press the **Set/Change** button.
 - To accept the digit value, press the **Menu/Enter** button.
 - Once A.M. or P.M. is accepted, the next menu item will flash.

EXAMPLE [A]

- 4** To set **Hardness** an "H" will appear to enter Compensated
 - Hardness in grains per gallon (gpg) Default setting is 25 gpg.

EXAMPLE [H - 25]

- 5** To Exit Main Menu, press the **Menu/Enter** button.

NOTE If no buttons are pressed for 60 seconds, the Main Menu will be exited automatically.

Normal Operation

Home Display

Metered models alternate the Time of Day and Gallons left until the next regeneration. The meter will count down to zero (0000) and then regenerate at the scheduled time set.

Battery Back-Up (Uses a standard 9-volt alkaline battery. Battery not included.)

Features of Battery Back-Up:

- During power failures, the battery will maintain the time of day as long as the battery has power. The display is turned off to conserve battery power during this time. To confirm that the battery is working, press either button and the display will turn on for five (5) seconds.

- If power failure occurs while system is regenerating, the valve will motor to a shut off position to prevent constant flow to drain. Depending upon system pressure and other factors, it is possible to observe a reduced flow to drain during this step. After power is restored, the valve will return and finish the cycle where it left off prior to the power interruption.
- When used without battery back-up, during a power failure, the unit stops at its current point in the regeneration position and then restarts at that point when the power is restored. The time will be offset by the increment of time the unit was without power, so it is necessary to reset the time of day on the unit. No other system settings will be affected.

Starting Extra Regeneration Cycle

To Start **Delayed Extra Cycle**

EXAMPLE [1]

- If Days Remaining Until Next Regeneration does not read '1',,, press and hold the **Set/Change** button for 3 seconds until the display reads '1', or '0000' on metered models.
- Regeneration cycle will initiate at the next designated regeneration time.

To start **Immediate Extra Cycle** → First complete above step.

- With Days Remaining Until Next Regeneration at '1' or '0000',
- Press and hold the **Set/Change** button.
- After 3 seconds, the regeneration cycle will begin.

To **Fast Cycle** thru regeneration → First complete above 2 steps.

NOTE Press and hold the **Set/Change** button for 3 seconds to advance to the next cycle step. Fast Cycle is not necessary unless desired to manually step through each cycle step. (Repeat until valve returns to the home display)

Softeners		Default (Min)
Step 1	Backwash	10
Step 2	Brine & Rinse	60
Step 3	Rapid Rinse	10
Step 4	Brine Refill	9 lbs/ cu ft

Master Programming Mode

To enter Master Programming Mode, press and hold both buttons for 5 seconds.

NOTE All Master Programming functions have been preset at the factory. Unless a change is desired, it is **NOT** necessary to enter Master Programming Mode.

Regeneration Time (r)

EXAMPLE [r 2A]

- The time of day at which regeneration may take place is designated by the letter "r".
- Default regeneration time setting for **SOFTENERS is 2a**
- The first display digit indicates A.M. or P.M. To change the value, press the **Set/Change** button.
- Press **Menu/Enter** button to accept the value and move to the next digit.
- The second and third display digits indicate the hour at which the regeneration will occur.
- Change the digits with the **Set/Change** button and accept with the **Menu/Enter** button.
- After the entire display flashes, press the **Menu/Enter** button to move to the next menu item.

Regeneration Day Override (A) – Meter (Demand) Mode Only

- Press **Menu/Enter** button. This display is used to set the maximum amount of time (in days) the unit can be in service without regeneration. This setting is identified by the letter "A" in the left digit. Regeneration will begin at the scheduled time. A setting of zero will cancel this feature.
- Example: Override every 7 days (A-07), default setting, or cancel setting (A-00). Maximum is 29.

Regeneration Cycle Step Times (Steps 1, 2, 3, 4)

EXAMPLE [3 - 10]

- The next 4 displays set the duration of time in minutes for each regeneration cycle step.
- The step number which is currently modifiable is indicated on the far left of the display screen.
- The number of minutes allotted for the selected backwash step is displayed on the far right.
- Change the digit values using the **Set/Change** and **Menu/Enter** buttons as described above.

System Capacity in Grains (c)

- Press the **Menu/Enter** button. This display is used to set the system capacity in grains and is used in conjunction with the hardness setting to calculate total gallons of treated water available between regenerations. This option is identified by the letter "c" in the left digit. The maximum value for this item is 399.

EXAMPLE 32,000 grain capacity (c 032).

Reserve Capacity Setting %

EXAMPLE [P - 25]

Bluetooth Enabled

bE - 1 (ON)

bE - 0 (OFF)

Bluetooth Password


bbPP is displayed for one second, then password is displayed.

To Exit the Master Programming Mode, press the **Menu/Enter** button until time of day returns.


NOTE

If no buttons are pressed for 60 seconds, the Master Programming Mode will be exited automatically.


Control Valve Assembly



Ref	Description	Part #	Qty.
0	Metered Power Head Assy.	21003X100	1
1	Softener Circuit Board Assy.	22003X102	1
2	Encoder	20001X124	1
3	Front Plate	20001X004	1
4	Encoder Wheel	20001X007	1
5	Main Gear	21001X120	1
6	Power Supply	20001X125	1
7	Back Plate	20001X005	1
8	Lower Front Base For Cover	20111X002	1
9	Legacy View Motor Assy.	20016X006	1
10	Lower Back Base for Cover	20111X003	1
11	Valve Cover	20111X017	1
12	6 X 1/2" Slotted, Hex Head	20001X003	1
13	6 X 1/2" Phillips, Pan Head	SC10	3
14	6 X 1/2" Slotted, Hex Head Blk	SC9	2
15	6 X 1/2 Fenderwasher SST	20001X002	1
16	Washer Circuit Board	20111X014	1
17	6-32 X 5/16" Phillips, Pan Head	SC2	1
21	10-24 X 3/4" Screw SST	20001X001	2



Ref	Description	Part #	Qty.
1	Piston Assembly	20001X231	1
2	10-24 X 3/4" Screw SST	20001X001	3
3	Seal and Spacer Kit	20561X253	1
4	End Spacer	20001X234	1
5	Flow Control Button 1.5 GPM	20251X266	1
	Flow Control Button 2.0 GPM	20251X267	1
	Flow Control Button 2.4 GPM	20251X268	1
6A	DLFC Assy.	20017X251	1
7	90 Degree Hose Barb Elbow	20017X266	1
8	Brine Valve	20561X225	1
9	Brine Line Connection	20561X006	1
10	10-24 X 3/4" Screw SST	20001X001	2
11	Injector Cap	20001X223	1
12	Injector Cap Seal	20001X224	1
13	Injector, White	20017x219	1
	Injector, Blue	20017x220	1
14	Injection Screen	20001X222	1
15	Plug	20001X217	1
16	Tank. O-Ring	20015X043	1
17	Dist. O-Ring	20561X204	1
18	Meter Assembly	20017X203	1



Ref	Description	Part #
1	D15 Bypass (included with all units)	20017X283
2	1" NPT Elbow Set (included with all units)	20017X284

Service Instructions

A General Preliminary Instructions

Perform Before All Servicing Operations

1. Turn off water supply to conditioner.
 - If the conditioner installation has a “three valve” bypass system, first open the valve in the bypass line, then close the valves at the conditioner inlet and outlet.
 - If the conditioner has an integral bypass valve, put it in the bypass position.
 - If there is only a shut off valve near the conditioner inlet, close it.
2. Remove cover and relieve water pressure in the conditioner by stepping the control into the backwash position momentarily. Return the control to the service position.
3. Unplug electrical cord from outlet.

B To Replace Powerhead

1. Remove the control valve cover and disconnect the power supply.
2. Disconnect the meter cable from circuit board and feed back through control (if existing meter is being re-used)
3. Remove lower back base screws and detach lower back base.
4. Remove screw and washer at drive yoke. Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily.
5. Put new powerhead on top of the valve. Be sure the drive pin on main gear engages slot in drive yoke (wide side of drive yoke upright must face to the left away from the motor).
6. Replace powerhead mounting screws. Replace screw and washer at drive yoke.
7. Reattach lower back base.
8. Reconnect meter signal, wire and power supply.
9. Reinstall cover.

C To Replace Piston Assembly

1. Follow steps **A1 - A3**
2. Disconnect the meter signal wire from the circuit board.
3. Remove lower back base screws and detach lower back base.
4. Remove screw and washer at piston drive yoke. Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily.
5. Remove piston retaining plate screws.
6. Pull upward on end of piston yoke until assembly is out of valve.

1. Inspect the inside of the valve to make sure that there is no foreign matter that would interfere with the valve operation.
2. Install new seals and spacers.
3. Take new piston assembly and push piston into valve by means of the end plug. Twist drive yoke carefully in a clockwise direction to properly align it with drive gear. Reinstall piston retaining plate screws.
4. Follow steps **B5 - B9**

D To Replace Seals and Spacers

1. Follow steps **A1 - A3**.
2. Disconnect the meter signal wire from the circuit board.
3. Remove screw and washer at piston drive yoke. Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily. Remove piston retaining plate screws.
4. Pull upward on end of piston rod yoke until assembly is out of valve. Remove seals and spacers. (Note: Special end spacer must be reused)
5. Lubricate new seals with silicone lubricant included in the seal and spacer kit. Make sure the special end spacer is properly seated in the valve body. Install new seals and spacers individually, pressing around the outer edge of each seal to make sure it is seated. (When all seals and spacers are seated properly, you will have a 1/4" of space between the top seal the the top of the valve body)
6. Follow Steps **C9 - C10**.

E To Service Injector and Screen

1. Follow steps **A1 - A2**.
2. Unscrew injector cover screws and remove injector cover.
3. Remove injector screen and clean or replace.
4. Remove injector and clean or replace.
5. Apply silicone lubricant to injector seal and replace cover and screws.

F To Replace Meter

1. Follow steps **A1 - A3**
2. Unplug meter cable from front of circuit board.
3. Unscrew meter assembly nut from valve body.
4. Remove meter from valve body and clean or replace as necessary.
5. Reinstall meter, nut and cable.

G To Replace Brine Valve

1. Follow Piston Replacement instructions. After the piston is removed, pull the brine valve from the valve body.
2. Inspect brine valve cavity in valve body and remove any foreign matter that would interfere with brine valve operation. Unscrew meter assembly nut from valve body.
3. Apply silicone lubricant to brine valve O rings and push the new brine valve into the valve body.
4. Continue following Piston Replacement instructions to reinstall piston and powerhead

Symptom	Probable Cause	Correction
Softener Fails to Regenerate Automatically	Power supply plugged into intermittent or dead power source	Connect to constant power source
	Disconnected meter cable	Reconnect cable
	Improper control valve programming	Reset program settings
	Defective power supply	Replace power supply
	Meter is dirty or defective	Clean or replace meter assembly
	Defective Drive motor	Replace motor
Regeneration at Wrong Time	Time of day improperly set, due to power failure	Reset time of day programming and install 9-volt battery.
	Regeneration time set improperly	Reset regeneration time programming
Loss of Capacity	Increased raw water hardness	Increase hardness setting or decrease days between regeneration
	Brine concentration and or / quantity	Keep brine tank full of salt at all times. Clean it yearly. Salt may be bridged. If using a salt grid plate, ensure refill water is over it.
	Resin fouling	Call Kind Water's Technical Support at 833-390-2959. Find out how to confirm it. Clean the resin and prevent future fouling.
	Poor distribution, channeling (uneven bed surface)	Call Kind Water's Technical Support at 833-390-2959. Check backwash flow. Regenerate more frequently
	Internal valve leak	Call Kind Water's Technical Support at 833-390-2959. Replace spacers, seals and / or piston
	Resin age	Call Kind Water's Technical Support at 833-390-2959. Check for resin oxidation caused by chlorine. Mushy resin.
	Resin loss	Call Kind Water's Technical Support at 833-390-2959. Check for correct bed depth. Broken distributor tube. Air or gas in bed: well gas eliminator. Loose brine line.

Symptom	Probable Cause	Correction
Poor Water Quality	Check items listed in #1, #2, and #3	
	Bypass valve open	Close bypass valve.
	Channeling	Check for too slow or high service flow. Check for media fouling.
High Salt Usage	High salt setting	Lower brine tank refill time
	Excessive water in brine tank	See symptom #7
	Constant flow through the unit	Indicates plumbing leak (e.g. toilet tank)
	Regenerating too frequently	Lower hardness setting or increase days between regeneration.
Loss of Water Pressure	Scaling / fouling of inlet pipe	Clean or replace pipeline. Pretreat to prevent.
	Fouled resin	Clean resin. Pretreat to prevent.
	Improper backwash setting	Backwash more frequently
Excessive Water in Brine Tank and / or Salty Water to Service	Plugged drain line or drain line control	Check flow to drain. Clean drain line flow control button
	Dirty or damaged brine valve	Clean or replace brine valve.
	Plugged injector or screen	Clean or replace injector screen.
	Low inlet pressure	Increase pressure to allow injector to perform properly. (20 psi minimum)
	Excessive brine refill cycle time	Lower brine refill time.

Symptom	Probable Cause	Correction
Softener Fails to Use Salt	Check items listed in #1	
	Improper control valve programming	Check and reset programming
	Plugged / restrict drain line	Clean drain line and / or flow control button
	Injector and / or screen is plugged	Clean or replace injector and screen
	No water in brine tank	Check for restriction in BLFC. Ensure safety float is not stuck. Check brine tank for leaks.
	Water pressure is too low	Line pressure must be at least 20 psi.
	Brine line injects air during brine draw	Check brine line connections for air leaks
	Internal control leak	Call Kind Water's Technical Support at 833-390-2959. Check piston, seals and spacers for scratches and dents.
Continuous Flow to Drain	Foreign material in control piston and seals	Call Kind Water's Technical Support at 833-390-2959. Clean valve and replace piston and seals.
	Internal control leak	Same as above.
	Valve jammed in backwash, brine or rapid rinse position	Same as above.
	Motor stopped or jammed	Check for jammed piston. Replace piston and seals. Replace motor if motor is unresponsive.

Control Valve Error Code Diagnosis

Under normal operating conditions, when your control valve is in the “in service” position, the display should alternate between the current time of day and the number of days remaining (for filters and time clock softeners) or gallons remaining (for metered softeners) until the next regeneration. This is the “home display.” If the valve is currently going through a regeneration cycle, the display will show the cycle step on the left side of the display and the number of minutes remaining in that step on the right side of the display. If any other information is being displayed, then the valve is informing you of an issue. There are five error codes which could indicate an issue with the control valve. When an error is being displayed, the valve will be in a stopped position, and the buttons will not respond to being pressed. Even if the cause of the error code is corrected, the error code will not clear until the power supply has been disconnected and reconnected (this will be referred to as “cycling” the power). All error codes are displayed as the letters “Err” followed by a flashing number 2-6:

Error 2 - Valve is searching for homing slot.

Allow valve to continue running. If the homing slot is found, the valve will return to the home display, otherwise, another error code will appear.

Error 3 - No encoder slots are being seen.

This occurs when the motor is running, but the encoder is not seeing any of the slots in the encoder wheel. This can happen if the encoder has been disconnected, but most commonly occurs when debris in the valve body has stopped the piston, causing the encoder wheel to be unable to turn.

1. Check encoder connection. If the encoder is plugged in and snapped into place, skip to step #2 below. If encoder is disconnected, reconnect it and cycle power to clear the error.
2. Disconnect powerhead from valve body, cycle power to clear the error code. Manually cycle the power head through the regeneration cycle steps to verify that the motor can cycle properly while the powerhead is disconnected from the valve body. If the error 3 does not reappear, skip to step #3 below. If the error 3 does reappear, order a board & motor kit to replace the circuit board & motor.
3. Remove piston and seals from the valve body and inspect valve body for debris. Replace the seal & spacer kit. Inspect piston and replace piston if Teflon coating is worn

Error 4 - Unable to find homing slot.

1. Check encoder wheel for debris.
2. Cycle power. Valve should either find home or go to a different error code. If error 4 returns, replace powerhead assembly.

Error 5 - Motor overload.

This occurs when the motor current is too high. This could be caused by an issue with the motor itself, but is typically caused by friction in the valve body

1. Disconnect powerhead from valve body and cycle power to clear the error code.
2. If the error 5 returns, replace the motor. Otherwise, manually cycle the powerhead through the regeneration cycle steps to verify that the motor can cycle properly while the powerhead is disconnected from the valve body. Either way, proceed to the next step.

Warranty

3. Remove piston and seals from the valve body and inspect valve body for debris. Replace the seal & spacer kit. Inspect piston and replace piston if Teflon coating is worn.

Error 6 - No motor current.

This typically occurs if the motor cable has come unplugged from the circuit board. Check that the motor cable is plugged into the circuit board and attached to the motor. If this is not the issue, the motor or circuit board may need to be replaced.

No Display

If your display is blank, there is no power going to the circuit board due to one of the following factors:

- The electrical outlet is not powered or is switched off
- The power cable has come unplugged from the circuit board
- The power supply has come unplugged from your electrical outlet
- The power supply has come unplugged from the control valve
- The power supply is not working

Water Treatment Equipment

For all Warranty information please visit www.kindwater.com/storepolicy/.

